

28 019 979

	Light Gold	28 019 979-26
	Chrom	28 019 979-00 0010
	Platin gebürstet	28 019 979-06 0010
	Platin	28 019 979-08 0010
	Dark Chrome	28 019 979-19 0010
	Light Gold	28 019 979-26 0010
	Light Gold gebürstet	28 019 979-27 0010
	Messing gebürstet (23kt Gold)	28 019 979-28 0010
	Schwarz matt	28 019 979-33 0010
	Bronze gebürstet	28 019 979-42 0010
	Champagne gebürstet (22kt Gold)	28 019 979-46 0010
	Champagne (22kt Gold)	28 019 979-47 0010
	Chrom gebürstet	28 019 979-93 0010
	Dark Platinum gebürstet	28 019 979-99 0010



**Brause**

SERIENNEUTRAL

---

28 019 979



**Brause**

SERIENNEUTRAL

---

28 019 979



**Brause**

SERIENNEUTRAL

---

28 019 979



Brause

SERIENNEUTRAL

28 019 979

## Ersatzteilstückliste