

10 713 809



- for controlling a waste disposal unit

Compatible with waste disposal units with integrated air switch made by Insinkerator®, e.g. Evolution.



The products are not available in all markets, please contact your Dornbracht sales force.

For more information go to www.insinkerator.com

| | | |
|---|-------------------------------|---------------|
|  | Dark Chrome | 10 713 809-19 |
|  | Chrome | 10 713 809-00 |
|  | Brushed Platinum | 10 713 809-06 |
|  | Platinum | 10 713 809-08 |
|  | Durabross (23kt Gold) | 10 713 809-09 |
|  | Brushed Durabross (23kt Gold) | 10 713 809-28 |
|  | Matte Black | 10 713 809-33 |
|  | Brushed Champagne (22kt Gold) | 10 713 809-46 |
|  | Champagne (22kt Gold) | 10 713 809-47 |
|  | Brushed Chrome | 10 713 809-93 |
|  | Brushed Dark Platinum | 10 713 809-99 |


10 713 809

mm [inches]



10 713 809

Parts for other finishes can be found here: [Chrome](#)



Spare parts list

| No. | Item Number | Name | Quantity used | Delivery time |
|--|--------------------|------------|---------------|---------------|
| 1 | 09 28 10 141 90 | sleeve | 1 | 2 |
| 2 | 90 27 80 034 00-19 | rosette | 1 | - |
| Spare part can no longer be ordered, please order the replacement item | | | | |
| 3 | 09 14 10 507 90 | seal | 1 | 2 |
| 4 | 90 21 33 052 00-19 | Pushbutton | 1 | - |
| Spare part can no longer be ordered, please order the replacement item | | | | |
| 5 | 09 14 10 015 90 | seal | 1 | 2 |
| 6 | 90 24 01 033 00 90 | ring | 1 | 2 |
| 7 | 09 14 10 210 90 | seal | 1 | 2 |
| 8 | 04 30 01 186 00 90 | sleeve | 1 | 2 |