

AIR SWITCH Control button - Chrome

10 714 970 Product version from 4/1/2025














- for controlling a waste disposal unit

Compatible with waste disposal units with integrated air switch made by Insinkerator®, e.g. Evolution.

The products are not available in all markets, please contact your Dornbracht sales force.

For more information go to www.insinkerator.com

Fits LOT

	Chrome	10 714 970-00
	Brushed Platinum	10 714 970-06
	Platinum	10 714 970-08
	Durabrand (23kt Gold)	10 714 970-09
	Dark Chrome	10 714 970-19
	Brushed Durabrand (23kt Gold)	10 714 970-28
	Brushed Bronze	10 714 970-42
	Brushed Champagne (22kt Gold)	10 714 970-46
	Champagne (22kt Gold)	10 714 970-47
	Brushed Chrome	10 714 970-93
	Brushed Dark Platinum	10 714 970-99

AIR SWITCH Control button - Chrome

10 714 970 Product version from 4/1/2025

mm [inches]



AIR SWITCH Control button - Chrome

10 714 970 Product version from 4/1/2025

Parts for other
finishes can be found
here: Brushed
Platinum



Spare parts list

No.	Item Number	Name	Quantity used	Delivery time
1	09 28 10 141 90	sleeve	1	2
2	09 27 87 013-00	rosette	1	10
3	09 14 10 507 90	seal	1	2
4	09 21 33 045-00	insert	1	10
5	09 14 10 015 90	seal	1	2
6	09 24 01 030 90	ring	1	2
7	09 14 05 037 90	seal	1	2
8	04 30 01 186 00 90	sleeve	1	2