

Strainer remote control with turning knob - Chrome

10 711 970



- Remote control for one sink only, for cable operated kitchen drains
- Including adapter for Bowden cable

Not compatible with brushed stainless steel kitchen sinks 38 XXX 004-86.

Fits LOT

	Chrome	10 711 970-00
	Brushed Platinum	10 711 970-06
	Platinum	10 711 970-08
	Durabrand (23kt Gold)	10 711 970-09
	Dark Chrome	10 711 970-19
	Brushed Durabrand (23kt Gold)	10 711 970-28
	Matte Black	10 711 970-33
	Brushed Champagne (22kt Gold)	10 711 970-46
	Champagne (22kt Gold)	10 711 970-47
	Brushed Chrome	10 711 970-93
	Brushed Dark Platinum	10 711 970-99

Strainer remote control with turning knob - Chrome

10 711 970


mm [inches]



Strainer remote control with turning knob - Chrome

10 711 970

Parts for other
finishes can be found
here: Brushed
Platinum



Spare parts list

Number	Item Number	Designation	Number of units	Lead time
1	09 20 97 030-00	handle	1	10
2	90 12 12 002 00 90	fixing cap	1	2
3	09 27 87 007-00	rosette	1	10
4	90 14 10 043 00 90	seal	1	2
5	09 14 10 042 90	seal	1	2
6	09 29 06 087-00	spindle	1	10
7	04 30 01 029 00 90	adaptor	1	2
8	09 24 03 175 90	adaptor	1	2
9	09 11 10 073-07	connection	1	30
10	09 11 10 074-07	connection	1	30
11	09 11 10 079-07	connection	1	30
12	09 30 11 087 90	disc	1	2
13	09 23 30 024-07	nut	1	30