













Strainer remote control with turning knob - Brushed Platinum

SERIES-VARIOUS

10 711 970




- Remote control for one sink only, for cable operated kitchen drains
  - Including adapter for Bowden cable
- Not compatible with brushed stainless steel kitchen sinks 38 XXX 004-86.
- Fits LOT

	Brushed Platinum	10 711 970-06
	Chrome	10 711 970-00
	Platinum	10 711 970-08
	Durabrand (23kt Gold)	10 711 970-09
	Dark Chrome	10 711 970-19
	Brushed Durabrand (23kt Gold)	10 711 970-28
	Matte Black	10 711 970-33
	Brushed Champagne (22kt Gold)	10 711 970-46
	Champagne (22kt Gold)	10 711 970-47
	Brushed Chrome	10 711 970-93
	Brushed Dark Platinum	10 711 970-99

10 711 970

mm [inches]



10 711 970

Parts for other  
finishes can be found  
here: [Chrome](#)



## Spare parts list

Number	Item Number	Designation	Number of units	Lead time
9	09 11 10 073-07	connection	1.00	30
1	09 20 97 030-06	handle	1.00	10
3	09 27 87 007-06	rosette	1.00	10
7	04 30 01 029 00 90	adaptor	1.00	2
12	09 30 11 087 90	disc	1.00	2
6	09 29 06 087-06	spindle	1.00	-
Spare part can no longer be ordered, please order the replacement item				
5	09 14 10 042 90	seal	1.00	2
13	09 23 30 024-07	nut	1.00	30
8	09 24 03 175 90	adaptor	1.00	2
2	90 12 12 002 00 90	fixing cap	1.00	2
11	09 11 10 079-07	connection	1.00	30
10	09 11 10 074-07	connection	1.00	30
4	90 14 10 043 00 90	seal	1.00	2