

## Flush plate For flush-mounted tanks from Geberit , angular - Brushed Light Gold

SERIES SPECIFIC

12 665 980 Product version from 4/1/2024




- Cover plate 6-5/8" x 9-5/8" x 1/2"
- Mechanical flush plate with manual activation
- For dual flush systems
- Incl. mounting frame, actuator rods and mounting elements
- Sound-insulated push rods, quickly adjustable without tools
- Compatible with all tanks in the Geberit Sigma series from 2001 onwards

Not compatible with GEBERIT Duo Fresh module

|   |                               |               |
|---|-------------------------------|---------------|
|    | Brushed Light Gold            | 12 665 980-27 |
|    | Chrome                        | 12 665 980-00 |
|    | Brushed Platinum              | 12 665 980-06 |
|    | Platinum                      | 12 665 980-08 |
|    | Durabrass (23kt Gold)         | 12 665 980-09 |
|    | Dark Chrome                   | 12 665 980-19 |
|    | Light gold                    | 12 665 980-26 |
|    | Brushed Durabrass (23kt Gold) | 12 665 980-28 |
|    | Matte Black                   | 12 665 980-33 |
|   | Brushed Bronze                | 12 665 980-42 |
|  | Brushed Champagne (22kt Gold) | 12 665 980-46 |
|  | Champagne (22kt Gold)         | 12 665 980-47 |
|  | Brushed Chrome                | 12 665 980-93 |
|  | Brushed Dark Platinum         | 12 665 980-99 |

**Flush plate For flush-mounted tanks from Geberit , angular - Brushed Light Gold** SERIES SPECIFIC

12 665 980 Product version from 4/1/2024  
mm [inches]



Flush plate For flush-mounted tanks from Geberit , angular - Brushed Light Gold

SERIES SPECIFIC

12 665 980    Product version from 4/1/2024  
Parts for other  
finishes can be found  
here: Chrome



Spare parts list

| Number | Item Number        | Designation | Number of units | Lead time |
|--------|--------------------|-------------|-----------------|-----------|
| 1      | 90 28 01 030 00 90 | base        | 1.00            | 2         |
| 3      | 90 28 10 212 00 90 | base        | 2.00            | 2         |
| 2      | 90 20 98 000 00-27 | button      | 2.00            | 30        |
| 4      | 90 11 98 012 00-27 | cover       | 4.00            | 30        |
| 5      | 90 14 05 090 00 90 | ring        | 1.00            | 2         |